



AVIGILON[™]UNITY

HID Mercury Access Control Hardware Installation Guide


Contents

AC-MER-CON-MR52 (Mercury MR52) 3

AC-MER-CON-MR52 (Mercury MR52)

Two Reader Interface Panel

The AC-MER-CON-MR52 supports two card readers, eight general-purpose input monitor points and six control relays. It is a downstream subpanel that works with control panels to provide access control and security monitoring.



Specifications

Panel Wiring

Reader Wiring

Input Wiring

Output Wiring

Powering the Panel

LED Indicators

More Information & Support

For additional product documentation and software and firmware upgrades, visit support.avigilon.com.

Contact Avigilon Technical Support at support.avigilon.com/s/contactsupport.

©2026, Avigilon Corporation. All rights reserved. MOTOROLA, MOTO, MOTOROLA SOLUTIONS, and the Stylized M Logo are trademarks or registered trademarks of Motorola Trademark Holdings, LLC and are used under license. All other trademarks are the property of their respective owners. Unless stated explicitly and in writing, no license is granted with respect to any copyright, industrial design, trademark, patent or other intellectual property rights of Avigilon Corporation or its licensors.

Avigilon Corporation
avigilon.com

PDF generated on 04 24, 2026

See the Motorola Solutions terms of use at motorolasolutions.com/en_us/about/terms-use.html

